


User information

Smoke Alarm Genius Plus / Plus X

Product overview

- 1 Smoke alarm (incl. fixed batteries)
- 2 Base
- 3 Magnetic holder
- 4 Hole for 1-hole installation
- 5 Long holes for 2-hole installation
- 6 Dowel
- 7 Screw
- 8 Test button with LED
- 9 Acoustic alarm
- 10 Anti-tamper seal opening
- 11 Adhesive pad



Muting of status signals

By pressing the test button **8** on the smoke alarm all status signals, messages and alarms can be muted.



Ready for use	Fault	End of life cycle
<p>Flashes green every 48 seconds. At night the LED is deactivated: Everything is fine. Your Genius protects you.</p> <p>You don't have to do anything.</p>	<p>Flashes red every 8 seconds. Fault signal every 48 seconds.</p> <p>The smoke alarm must be replaced immediately. Please contact your landlord or caretaker.</p>	<p>Flashes orange every 8 seconds and beeps every 48 seconds: This smoke alarm is at the end of its life cycle.</p> <p>The smoke alarm must be replaced immediately. Please contact your landlord or caretaker.</p>

Alarm

Red flashing, loud alarm signal: Your smoke alarm has detected smoke. Danger!

Case A

- Warn your roommates.
- Leave the room / building immediately. Close all doors on your way out to prevent smoke and fire from spreading quickly.
- Stay close to the floor in case of dense smoke.
- Do not call the fire brigade (**emergency 112**) until you are safe.

Information in case of fire

Case B

- If you are unable to leave the room / building due to a fire in the stairwell, close all doors, seal all cracks and slits and draw attention to yourself at the window.
- Do not call the fire brigade (**emergency 112**) until you are safe.

